


WARNING

- DO NOT FLY NEAR POWER LINES
- DO NOT PLACE NEAR ROADS RAILWAY LINES ETC.

TOP OF KITE

assemble kite by inserting the brace into the tubes on the top side of the kite



tie swivels at each end of the line with a good strong knot



tie swivels at each end of the line with a good strong knot



Pull out each section of the telescopic launch pole and twist to lock in place

ground stake - drive into ground with heavy hammer to a depth of 50cm max



adjust length of the line so tip of tail is 1m above the crop



support disc fits around ground stake



launch pole slides over ground stake and rests on support disc

10-20'

60cm

50cm

High winds

The TERROR KITE will fly well in light breezes and strong winds. If gale force winds are forecast, it is advisable to tether the kite and launch pole to a tent peg (not provided) or similar using the cleat located at the base of the launch pole.